
QUICK START GUIDE




1) DISCONNECT 115VAC POWER CIRCUIT BEFORE MAKING ANY WIRING CONNECTIONS




2) INSTALL ALL CLOCKS WITH CLOCK HANDS POINTING AT 12:00



3) INSTALL 99B-MI CLOCK CONTROLLER (#10 SCREWS RECOMMENDED)



- 4) CONNECT 99B-MI CLOCK CONTROLLER TO CLOCKS (24VAC - 16AWG RECOMMENDED)
 - 4 OUTPUTS PROVIDED LABELED "MI CLOCK" 1-4
 - "HOME RUN" WIRING RECOMMENDED FROM EACH CLOCK TO 99B-MI OUTPUTS "MI CLOCK" 1-4
 - SHIELDED CABLE RECOMMENDED, CONNECT SHIELD ONLY TO 99B-MI, TRIM SHIELD AT CLOCK MOVEMENTS



- 5) CONNECT 115VAC BRANCH CIRCUIT TO 99B-MI CLOCK CONTROLLER
- 6) TURN ON 115VAC POWER
- 7) CLOCKS WILL AUTOMATICALLY RESET TO CORRECT TIME

REFERENCE MANUAL 274 FOR COMPLETE OPERATION & MAINTENANCE INSTRUCTIONS

